

INSTALLATION AND WIRING:

1. Mount the switch housing on the floor as close as possible to the inside of both the door and the door frame.
2. Bend the flexible armor so that the wires are led to the side of the door where the protective circuit is to be picked up.
3. Mount the magnet on the door so that it extends out over the switch housing. The magnet should line up between the two raised lines on top of the switch housing and be installed so that an alarm is actuated before a 2" clear opening is reached.
4. a. Connect the two longer leads (they are the switched pair) in series with the positive (+) side of the protective circuit.
b. Connect the two shorter leads (they are the continuous pair) in series with the negative (-) side of the protective circuit or, alternatively, in a separate tamper loop.

