



If using No. 716 CABINET
Assemble as indicated here.
Use No. 8-32 hardware.

- 1. MOUNT OUTER CABINET:** Remove inner assembly from cabinet. Mounting holes and knockouts are provided at rear of outer cabinet. Outer cabinet louver openings must face downward.
 - 2. RE-ORIENT SPEAKER PLATE IF LEFT HAND AIMING DESIRED:** Unit is furnished as shown in diagram, with speaker aiming out of RIGHT side of cabinet.
To point speaker in the opposite direction, proceed as follows:
 - a. Remove 4 screws indicated by "A" in diagram. Leave speaker attached to front (tamper) plate.
 - b. Turn speaker plate 180° so that its louver openings face in opposite direction and replace the 4 "A" screws in positions similar to those previously used.
- Note:** FOR PROPER PROTECTION FROM VANDALS, SPEAKER PLATE (INNER) LOUVER OPENINGS MUST FACE UPWARD when inner assembly is replaced in outer cabinet.
- 3. MAKE WIRING CONNECTIONS:** To support inner assembly while wiring connections are made, rear angle of speaker plate may be hooked behind angle tab of cabinet, as shown in diagram.
 - 4. REPLACE INNER ASSEMBLY IN CABINET:** To repeat, speaker plate louver openings must face upward inside cabinet.