



F-642NDDOOR-HH SECOND DOOR TRANSMITTER INSTALLATION INSTRUCTIONS

GENERAL DESCRIPTION

Used with the F-64 DOOR DEMO sales tool, the F-642NDDOOR-HH transmitter allows Touchpad operation with a second door transmitter to be demonstrated.

The F-642NDDOOR-HH is a modified F-LTRANS transmitter and F-TAB deadbolt sensor. Its rotary dial provides three separate door conditions:

- Door Open
- Door Closed
- Deadbolt Locked

NOTE: The F-642NDDOOR-HH contains modifications for use with the F-64 DOOR DEMO. For example, quickly turning the F-642NDDOOR-HH dial from "Locked" to "Open" can generate a "kick-in" event ("kick-in" occurs when a "door open" transmission is received before a "deadbolt unlock" transmission). Because certain other features (such as Chime) did not operate correctly when a "kick-in" event occurs, the F-642NDDOOR-HH was modified to prevent "kick-in" transmissions. In addition, the invalid condition of "door open and deadbolt locked" is not provided thus eliminating the need for extended explanations about how the system treats this condition. Because of these modifications, the F-642NDDOOR-HH should only be used with the F-64 DOOR DEMO and never in real installations.

PROGRAMMING

Program the F-64 DOOR DEMO comes programmed in the same manner as a new factory default panel, mapping the Touchpad doors and PIR as follows:

- Touchpad Door 1 to Zone 9
- Touchpad Door 2 to Zone 10
- PIR Alarm to Zone 11

In addition, the F-64 DOOR DEMO is also programmed with the undocumented feature "Disable the Low Battery Display". Enter **Touchpad Configuration Mode** to learn the F-642NDDOOR-HH as the secondary door transmitter.

Napco Security Systems, Inc.
333 Bayview Avenue
Amityville, New York 11701
Sales, Repairs & Technical Service (Toll Free): (800) 645-9445
Technical Service Direct Line (Toll Free): (800) 645-9440
Publicly traded on NASDAQ Symbol: NSSC